

#	Part No.	Description	Per Tool
2	94-771602	Air Inlet	1
3	94-771603	Handle	1
4	94-771604	Lever	1
5	94-771605	Lever Pin	1
6	94-771606	Valve Bushing	1
7	94-771607	Valve Stem	1
8	94-771608	O Ring	1
9	94-771609	Valve Spring	1
10	94-771610	Regulator	1
11	94-771611	O Ring	1
12	94-771612	Valve Screw	1
13	94-771613	Gasket	1
15	94-771615	Bearing	1
16	94-771616	Rear End Plate	1
17	94-771617	Rotor Blade	4 set
18	94-771618	Rotor	1
19	94-771619	Cylinder Pin	1
20	94-771620	Cylinder	1
21	94-771621	Front End Plate	1
22	94-771622	Bearing	1
23	94-771623	Bearing	1
24	94-771624	Pinion (Sander)	1
24	94-7716P24	Pinion (Polisher)	1
25	94-771625	Housing Band	1
26	94-771626	Motor Housing	1
27	94-771627	Bearing	2 set
28	94-771628	Bevel Gear (Sander)	1
28	94-7716P28	Bevel Gear (Polisher)	1
29	94-771629	Spindle	1
30	94-771630	Woodruff Key	1
31	94-771631	Housing Cap	1
32	94-771632	Bearing	1
33	94-771633	Retaining Ring	1
35	94-771635	Handle	1
37	94-771637	Cap Screw	4 set
38	94-771638	Bearing Plate	1
39	94-771639	Exhaust Deflector	1
40	94-771640	Screw	2 set
41	94-771641	Retaining Ring	1
42	94-771642	Wave Washer	1
43	94-771643	Spring Washer	4 set
44	94-771644	Screw	4 set

#	Part No.	Description	Per Tool
45	94-771645	Wave Washer	1
46	94-771646	O Ring	1
47	94-771647	Locknut	1
48	94-T7472	Polishing Pad	1
49	94-T7470A	Spiral Back Up Pad	1
50	94-771650N	Flat Wrench	1
51	94-771651N	Spanner Wrench	1

